//About This Script: This is a comprehensive error check. In the event navigation is interrupted this script will identify that it has and attempt to navigate back to the correct location on screen. This will also check to make sure the remote image is still visible to the text reader and if not, attempt to correct that issue. This will also correct itself if the user's account crashes.//

params LoginID, MenuOption, ReadScreenSearchRectangle, MoviesMenuLocationRectangle

```
//MenuOption Not Found
Set NavigationCheck = "OFF"
Log "Attempting to fix possible navigation error"
Repeat 2 Times
       //Black Screen Issue
       //Scenario: Black screen with remote visible
       If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324)))
               If ImageFound(5, "Remote-Power_Button")
                       MoveTo (Image: "Remote-Power_Button", WaitFor: 10)
                       Click (Image: "Remote-Power Button", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand_Button", WaitFor: 10)
                      Click (Image: "Remote-OnDemand Button", WaitFor: 10)
                      Wait 10
                       If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                              Set NavigationCheck = "ON"
                              Exit Repeat
                       End If
               End If
       End If
       //Scenario: Black screen with remote not visible
       If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324)))
               If ImageFound(5, "Remote-Power_Button") = No
                       If ImageFound(5, (Image: "Remote Toggle On Off", SearchRectangle: (656,64,1030,228)))
                              Click(Image: "Remote Toggle On_Off", SearchRectangle: (656,64,1030,228))
                              Wait 2
                              MoveTo (Image: "Remote-Power Button", WaitFor: 10)
                              Click (Image: "Remote-Power_Button", WaitFor: 10)
                              Wait 8
                              MoveTo(Image: "Remote-OnDemand Button", WaitFor: 10)
                              Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                              Wait 10
                              If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                                      Set NavigationCheck = "ON"
```

```
Exit Repeat
                       End If
               End If
       End If
End If
//Reconnect Issue
//Scenario: Check for Reconnect issues, tv off and remote visible
If ImageFound(5, (Image: "Reconnect_ErrorButton", SearchRectangle: (387,386,1048,655)))
       Click(Image: "Reconnect_ErrorButton", SearchRectangle: (387,386,1048,655))
       Wait 20
       If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324)))
               If ImageFound(5, "Remote-Power_Button")
                       MoveTo (Image: "Remote-Power Button", WaitFor: 10)
                       Click (Image: "Remote-Power_Button", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Click (Image: "Remote-OnDemand Button", WaitFor: 10)
                       Wait 10
                      If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                              Set NavigationCheck = "ON"
                              Exit Repeat
                       End If
               End If
       End If
       //Scenario: Check for Reconnect issues, tv off and remote not visible
       If ImageFound(5, "Remote-Power Button") = No
               If ImageFound(5, (Image:"Remote Toggle On_Off", SearchRectangle:(656,64,1030,228)))
                       Click(Image: "Remote Toggle On_Off", SearchRectangle: (656,64,1030,228))
                      Wait 2
                      If ImageFound(5, "Remote-Power_Button")
                              MoveTo (Image: "Remote-Power Button", WaitFor: 10)
                              Click (Image: "Remote-Power Button", WaitFor: 10)
                              Wait 8
                              MoveTo(Image: "Remote-OnDemand Button", WaitFor: 10)
                              Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                              Wait 10
                              If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                                      Set NavigationCheck = "ON"
                                      Exit Repeat
```

```
End If
                       End If
               End If
       End If
       //Scenario: Check for Reconnect issues, tv on and remote visible
       If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324))) = No
               If ImageFound(5, "Remote-Power Button")
                       MoveTo (Image: "Remote Exit", WaitFor: 10)
                       Click (Image: "Remote_Exit", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand Button", WaitFor: 10)
                       Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Wait 10
                       If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                              Set NavigationCheck = "ON"
                              Exit Repeat
                       End If
               End If
       End If
End If
//Logged On Conflict
//Scenario: Someone else logged on and kicked us out, tv on and remote detected
If ImageFound(5, (Image:"LoggedIn_ConflictIndicator", SearchRectangle:(323,290,908,546)))
       Click(Image:"LoggedIn_ConflictIndicator", SearchRectangle:((315,278,915,557)))
       Wait 10
       If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324))) = No
               If ImageFound(5, "Remote Exit")
                       MoveTo (Image: "Remote_Exit", WaitFor: 10)
                       Click (Image: "Remote_Exit", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Click (Image: "Remote-OnDemand Button", WaitFor: 10)
                       Wait 10
                       If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                              Set NavigationCheck = "ON"
                              Exit Repeat
                       End If
               End If
       End If
       //Scenario: Someone else logged on and kicked us out, tv off and remote detected
```

```
If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324)))
               If ImageFound(5, "Remote-Power_Button")
                       MoveTo (Image: "Remote-Power_Button", WaitFor: 10)
                       Click (Image: "Remote-Power Button", WaitFor: 10)
                       Wait 8
                       MoveTo (Image: "Remote_Exit", WaitFor: 10)
                       Click (Image: "Remote_Exit", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Wait 10
                       If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                              Set NavigationCheck = "ON"
                              Exit Repeat
                       End If
               End If
        End If
       //Scenario: Someone else logged on and kicked us out, remote not detected
       If ImageFound(5, "Remote-Power_Button") = No
               If ImageFound(5, (Image: "Remote Toggle On_Off", SearchRectangle: (656,64,1030,228)))
                       Click(Image: "Remote Toggle On Off", SearchRectangle: (656,64,1030,228))
                       Wait 2
                       If ImageFound(5, "Remote_Exit")
                              MoveTo (Image: "Remote Exit", WaitFor: 10)
                              Click (Image: "Remote Exit", WaitFor: 10)
                              Wait 8
                              MoveTo(Image: "Remote-OnDemand Button", WaitFor: 10)
                              Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                              Wait 10
                              If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                                      Set NavigationCheck = "ON"
                                      Exit Repeat
                              End If
                       End If
               End If
       End If
//If Menu Option not found
//Scenario: Menu option not found, tv on
If ImageFound(5, (Image:"NoVideoSignal", SearchRectangle:(392,212,837,324))) = No
```

End If

```
If ImageFound(5, "Remote_Exit")
                       MoveTo (Image: "Remote_Exit", WaitFor: 10)
                       Click (Image: "Remote_Exit", WaitFor: 10)
                       Wait 8
                       MoveTo(Image: "Remote-OnDemand Button", WaitFor: 10)
                       Click (Image: "Remote-OnDemand_Button", WaitFor: 10)
                       Wait 10
                       If ImageFound(10, (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle)))
                               Set NavigationCheck = "ON"
                               Exit Repeat
                       End If
               End If
        End If
End Repeat
If NavigationCheck = "ON"
       If MenuOption <> "All Movies (HD)" and MenuOption <> "All Movies (SD)"
               MoveTo (Text: "Movies", SearchRectangle:(ReadScreenSearchRectangle))
               -- set the x and y coordinates of the text location
               put the x of mouselocation() into xT
               put the y of mouselocation() into yT
               -- set up your button grid based on the size of the screen
               set x0 = "370"
               set x1 = "600"
               set x2 = "830"
               set y0 = "354"
               set y1 = "380"
               set y2 = "411"
               set y3 = "441"
               set y4 = "471"
               set y5 = "501"
               -- navigate to the "Movies" button based on location of text
               If xT > x1 then
                       MoveTo (Image: "Remote RightArrow")
                       Click (Image: "Remote_RightArrow")
                       Wait 3
               End If
               if yT > y1 then
                       MoveTo (Image: "Remote_DownArrow")
                       Click (Image: "Remote_DownArrow")
               end if
```

```
if yT > y2 then
               MoveTo (Image: "Remote_DownArrow")
               Click (Image: "Remote_DownArrow")
       end if
       if yT > y3 then
               MoveTo (Image: "Remote_DownArrow")
               Click (Image: "Remote_DownArrow")
       end if
       if yT > y4 then
               MoveTo (Image: "Remote DownArrow")
               Click (Image: "Remote DownArrow")
       end if
       Wait 8
       MoveTo (Image: "Remote_Select")
       Click (Image: "Remote_Select")
       Wait 8
End If
If MenuOption = "All Movies (HD)" or MenuOption = "All Movies (SD)"
       If ImageFound(10, (Text: "Now In Theaters", SearchRectangle:(ReadScreenSearchRectangle)))
               MoveTo (Text: "Now In Theaters", SearchRectangle:(ReadScreenSearchRectangle))
       End If
       -- set the x and y coordinates of the text location
       put the x of mouselocation() into xT
       put the y of mouselocation() into yT
       -- set up your button grid based on the size of the screen
       set x0 = "370"
       set x1 = "600"
       set x2 = "830"
       set y0 = "354"
       set y1 = "380"
       set y2 = "411"
       set y3 = "441"
       set y4 = "471"
       set y5 = "501"
       -- navigate to the "Now In Theaters" button based on location of text
       If xT > x1 then
               MoveTo (Image: "Remote_RightArrow")
               Click (Image: "Remote_RightArrow")
               Wait 3
```

```
End If
              if yT > y1 then
                      MoveTo (Image: "Remote_DownArrow")
                      Click (Image: "Remote_DownArrow")
              end if
              if yT > y2 then
                      MoveTo (Image: "Remote_DownArrow")
                      Click (Image: "Remote_DownArrow")
              end if
              if yT > y3 then
                      MoveTo (Image: "Remote_DownArrow")
                      Click (Image: "Remote_DownArrow")
              end if
              if yT > y4 then
                      MoveTo (Image: "Remote_DownArrow")
                      Click (Image: "Remote_DownArrow")
              end if
              Wait 8
              MoveTo (Image: "Remote_Select")
              Click (Image: "Remote_Select")
              Wait 8
       End If
return NavigationCheck
```

End If